



# **Cable Pro Web™ Tutorial**

## **Protection Coordination**

13/04/2021

# Table of contents

Introduction .....	1
An example system .....	2
Add protective devices.....	4
Create coordination curves as per standards .....	6
Adjust device settings to achieve coordination .....	9
Determine the sequence of operation .....	10

## Introduction

The Protection Coordination module in Cable Pro Web™ allows the user to conduct a protection coordination study with over 5000 protective devices from different manufacturers. The protective devices can be easily selected, and the time current curves will be generated automatically.

The device settings which are designed as per manufacturer catalogues are used to plot the time current curves according to user adjustments. The module also features two functions – *Coordination criteria* and *Sequence of operation* – to help the user achieve the coordination between devices.

A detailed report including all device information and settings is able to be generated, which can be used as a commissioning report as well.

## An example system

To demonstrate how to use the Protection Coordination to achieve selectivity between devices, an example system is investigated. As Figure 1 shows, coordination is supposed to be achieved between an incoming circuit breaker protecting a distribution board and another circuit breaker protecting an outgoing distribution circuit.

The requirement is to specify the device settings that will achieve coordination for all levels of prospective fault current as per the Standards or the manufacturer guidelines. In the example herein the coordination criteria is based on Standard AS/NZS 3000:2018.




Figure 1 – Single line diagram

- **Rated currents and Max. prospective fault current**

The rated load current of the distribution circuit is 239 A while that of the incoming circuit is 694 A. The maximum prospective fault current at the outgoing distribution circuit is 7.2 kA.

- **Protective devices**

The circuit breaker for protecting distribution board is shown in Table 1.

Table 1 - Circuit breaker protecting distribution board

Manufacturer	Family	Model	Rating (A)	Trip unit
ABB	SACE Tmax. T Generation (Electronic)	T6S	320 - 800	PR222DS/P-LSI

The circuit breaker for protecting outgoing circuit is shown in Table 2.

Table 2 - Circuit breaker protecting outgoing circuit


<b>Manufacturer</b>	<b>Family</b>	<b>Model</b>	<b>Rating (A)</b>	<b>Trip unit</b>
ABB	SACE Tmax. XT	XT3S (Thermal-magnetic)	175 - 250	TMD

## Add protective devices

Go to any existing project or create a new project. Then create a new calculation with the calculation type of Protection Coordination.

- **Add the upstream protective device**

When first opening the Protection Coordination calculation, a popup for selecting the protective device will be shown – Protective Device Selector. With the Protective Device Selector, the upstream circuit breaker shown in Table 1 can be selected.



Protective Device Selector

Manufacturer  
ABB

Family  
SACE Tmax. T Generation (Electronic) MCCB

Model  
T6S - Icu 50kA

Rating (A)  
320-800

Trip unit  
PR222DS/P-LSI - distribution protection

Show breaking capacities

Cancel Accept

Figure 2 – Select the upstream circuit breaker at the distribution board

- **Add the downstream protective device**

Click **Add device** in the top of Single line diagram to open the Protective Device Selector again and add the device protecting outgoing circuit shown in Table 2.




Figure 3 – Add downstream protective device of the outgoing circuit

## Create coordination curves as per Standard

After adding the devices, the time current curves of devices will be shown automatically with default device settings. To achieve coordination, enough separation should be maintained between time current curves.

A useful tool is provided in the Protection Coordination calculation to help the user display the required spacing along with original time current curves – Coordination criteria. This tool visualises the coordination requirements of a Standard. The following steps will show you how.




Figure 4 – Time current curves of two devices with default settings

- **Coordination requirements stated in AS/NZS 3000:2018**


According to Clause 2.5.7.2.3 (a) (ii) and (iii), discrimination is deemed to be achieved if  $C_1 \geq 1.5 \times C_2$  when the rating of  $C_2$  is less than 800 A.  $C_2$  is the downstream time current curve while  $C_1$  is the upstream time current curve.

- **Create the coordination curve**



An imaginary curve which indicates the coordination requirement can be created with Coordination criteria. Click **Add** in the Coordination criteria tab to add a new row in the table, which represents a coordination curve in the plot.

The coordination curve will be based on the selected device original curve. In this case, the Outer curve of Device 02 should be selected as we desire to make sure there will be enough spacing between downstream outer curve and upstream inner curve.



Time current curves **Coordination criteria** Sequence of operation

Add Remove

Device	Curve	Current multiplier	Time multiplier	Time adder (s)	Show
Device 02	Outer	1.5	1	0	<input checked="" type="checkbox"/>

Figure 5 – Create the coordination curve as per standards

Specify **Current multiplier** as 1.5 to represent the coordination requirement from AS/NZS 3000:2018. Leave **Time multiplier** and **Time adder (s)** as default. The created coordination curve is shown in Figure 6 in blue as a line.




Figure 6 – Coordination curve based on downstream device

## Adjust device settings to achieve coordination

From Figure 6, for a fault current between 880 A and 4500 A (approximately), the coordination fails since the upstream device curve crosses the coordination curve (blue line) of the downstream device.

As per AS/NZS 3000:2018, discrimination need not apply above the arcing fault current ( $I_{arc}$ ). To be conservative, arcing fault current equals to 60% of prospective fault current which is  $7200 \times 0.6 = 4320$  A. Therefore, the device settings need to be adjusted to make sure the time current curves of upstream are on the right side of the coordination curve under 4320 A.

The rating (long time protection pick up current) of the upstream device is changed to 720 A to have adequate margin from the rated load current (694 A). The long-time protection time delay setting, and short time protection pick-up current are changed to 13 s and 5200 A respectively. Now discrimination between these two devices is achieved and is fully compliant.




Figure 7 – Discrimination is achieved between two devices

## Determine the sequence of operation


Sometimes the coordination needs to be achieved based on tripping time and not only current. The sequence of operation thereby needs to be determined at the specific fault level.

In the Protection Coordination module, the user can specify the current whether they want to know the sequence of operation. The tripping times and their differences will be displayed in the table and an auxiliary curve will be shown in the graph to indicate the sequence.

As Figure 8 shows, the minimum tripping time difference between upstream and downstream devices is 11.68 s at arcing fault current ( $I_{arc}$ ), 4320 A.

Device	Curve	Tripping time (s)	Difference (s)
Device 02	Inner	0.013	-
Device 02	Outer	0.019	0.006
Device 01	Inner	11.7	11.681
Device 01	Outer	14.3	2.6

(a) Tripping times and differences



(b) Auxiliary curve in the plot

Figure 8 – Sequence of operation